

Operating manual English

Revision	A
Date	16.06.2009
Created by	NH

This operating instruction is not subject to the updating

Low Pressure Clean-Break-Coupling

1-CT-005-0-.....-.....

1-CT-005-2-.....-.....

1-CT-007-0-.....-.....

1-CT-007-2-.....-.....

1-CT-009-0-.....-.....

1-CT-009-2-.....-.....

1-CT-012-0-.....-.....

1-CT-012-2-.....-.....

1-CT-019-0-.....-.....

1-CT-019-2-.....-.....

optional features:

EX, GG (only CT-019)



Vor Beginn aller Arbeiten
Betriebsanleitung lesen!

*Read operating instruction
before beginning of all works!*

Betriebsanleitung immer
AUFBEWAHREN!
griffbereit am Gerät

*Always **KEEP** operating
instruction! In a ready hand
way at the device*

Achtung: Vor Inbetriebnahme
Gerät auf mängelfreien Zustand
und technisch einwandfreie
Funktion kontrollieren.

*Caution: Before starting-up
check device on faultless
condition and technically
perfect function.*

Das Original ist die
deutsche Fassung

*The German version
is the original*

This coupling is a quality product, in which special attention has been paid to high functionality, ease of operation, safety and reliability. As an item of technical equipment this coupling is intended for use in the commercial, industrial area and for operators, who have been trained by specialists in the handling of technical systems / tools.

Customer care:

As part of our individual customer care we will be happy to assist you in questions relating to use and operation and on any problems encountered.

Service and maintenance:

In order to maintain the high technical performance capability and reliability of your coupling over many years, we recommend regular inspection and maintenance.

We can thereby offer you optimum support by our Customer Service department and the conclusion of a service and maintenance contract. Please ask for a quotation.

Carl Kurt Walther GmbH & Co. KG
PO Box 42 04 44
42781 Haan
Westfalenstraße 2

Tel.: +49 (0) 2129 567-0
Fax: +49 (0) 2129 567 450

E-Mail: info@walther-precision.de
Internet: www.walther-precision.de

Contact:

Application technology and service

Holger R. Figge
Telephone: (02129) 567-591
Telefax: (02129) 567-590
Handy: (0162) 2090100
e-mail: hfigge@walther-precision.de

Further addresses and telephone numbers of contacts can be found on the Internet on our homepage under www.walther-precision.de "Service / Customer service".-

Table of Contents

1	<u>Table of Contents</u>	
1	TABLE OF CONTENTS	3
2	GENERAL	4
3	WARRANTY	5
4	SAFETY INSTRUCTIONS	6
5	PRODUCT DESCRIPTION OF THE COUPLING	7
5.1	INTENDED USE	8
5.2	TECHNICAL DATA	8
5.3	OPTIONAL FEATURES	9
5.4	EXTENDED PRODUCT DESCRIPTION FOR APPLICATION ACC. TO ATEX-GUIDE LINE 94/9/EG (SPECIAL DESIGN EX):	9
5.4.1	<i>General</i>	9
5.4.2	<i>Extended marking</i>	9
6	INSTALLATION MANUAL	10
6.1	GENERAL	10
6.2	EXTENDED INSTALLATION INSTRUCTION FOR APPLICATION ACC. TO ATEX-GUIDELINE 94/9/EG	10
6.2.1	<i>Details for safe operation</i>	10
6.2.2	<i>Details for safe installation</i>	10
6.2.3	<i>Details for a safe application area</i>	10
7	OPERATING MANUAL	11
7.1	COUPLING PROCESS	11
7.2	UNCOUPLING PROCESS	11
8	MAINTENANCE AND FUNCTION TEST	12
8.1	MAINTENANCE	12
8.2	FUNCTION TEST	12
9	LUBRICATION !	13
10	STORAGE	14
11	SHUT-DOWN	15
12	ORDER NUMBERS CODE	16
13	INDEX	17

2 General

This manual contains all regulations for operation, commissioning and maintenance of the coupling CT-series.

All information and notes in this operating manual were collated while taking into consideration the valid regulations, the current engineering related status of development as well as our many years of experience and acquired knowledge.

Translations of this operating manual were also produced according to the best of knowledge. However, we cannot assume liability for any translation errors. The German version provided for this operating manual is considered the authoritative version.

The actual scope of delivery can deviate from the explanations and graphic representations described herein under certain circumstances, e.g. in the case of special designs, utilization of additional order options or because of state-of-the-art technical alterations.

If you have any questions, please contact the manufacturer.



This operating manual must be read carefully before starting work on or with the equipment, in particular before commissioning!

The manufacturer assumes no liability for damage or faults arising from non-compliance with the instructions in this operating manual.

The operating manual must be kept directly with the equipment and be accessible to all persons who work on or with the equipment.

It is not permitted for the operating manual to be passed to third parties and if applicable this will incur damage compensation.

All other rights reserved.

Before commissioning the device must be checked for being not defective and its technically perfect function.

The German version is the original.

We reserve the right to make technical alterations to the product within the context of improving the usage properties and further development.

The operating manual remains our property.

Any reproduction, use by or communication to third parties incurs a penalty and will be pursued by court action (copyright law against unfair competition, BGB [German Civil Code]).

All rights reserved in the case of a patent award (Paragraph 7, Section. 1 of the patent law - PG) or entry as a patented design (Paragraph 5, Section 4 of the patented design law - GMG).

3 Warranty

The warranty conforms to:

the regulations agreed in the purchase contract and
the “General Conditions for Delivery and Capacity” of C.K. Walther GmbH & Co. KG
of the state which was valid at the date of the purchase contract.

Wearing parts are generally excluded from the warranty.
Typical wearing parts of products from company C.K. Walther GmbH & Co. KG
are for example:

- seals
- springs

Safety instructions

4 Safety instructions

Using these couplings does not release the customer from his obligation to comply with the pertinent work safety regulations e.g. operational safety regulations, etc. The duty to take due care by the operator of the couplings includes planning measures to ensure proper operation and monitoring their implementation.


 Hazard notes

If the wrong product has been selected or if there is improper use or maintenance has been omitted, then hazards arise and personal injuries and material damage can occur from:

- hazardous emission of medium or individual particles/coupling parts.
- function impairments of connected systems or tools.
- the metal parts of coupling and adaptor are not thermally protected. In case of high media temperatures the contact with these parts can lead to combustion. According to the ambient temperature valve handle and ring grip can also become very hot. For that reason sufficiently long protective gloves must be worn in these cases.

 The operator must in particular make sure that

- the couplings are only used according to the intended purpose.
- the couplings are only operated in a perfect, functioning condition.
- the operating manual is always in a legible condition and is available in its entirety to operating personnel.
- the operating personnel are sufficiently acquainted with the working method and the safety notes for the coupling.
- no safety devices must be removed and/or deactivated during operation of the couplings.
- before installing or dismantling the couplings, you have made sure that the couplings have not been pressurized.

 After completing assembly and installation work and before commissioning the coupling, the following items have to be observed:

Check once again that all screw connections are securely fitted.

Before commissioning the couplings, a function test must be carried out (see maintenance and function test).

Product description of coupling

5 Product description of the coupling

Coupling connection consists of:

- | | |
|-------------------------|------------------------|
| - self sealing coupling | 1-CT-005-0-.....-..... |
| - self sealing adaptor | 1-CT-005-2-.....-..... |
| - self sealing coupling | 1-CT-007-0-.....-..... |
| - self sealing adaptor | 1-CT-007-2-.....-..... |
| - self sealing coupling | 1-CT-009-0-.....-..... |
| - self sealing adaptor | 1-CT-009-2-.....-..... |
| - self sealing coupling | 1-CT-012-0-.....-..... |
| - self sealing adaptor | 1-CT-012-2-.....-..... |
| - self sealing coupling | 1-CT-019-0-.....-..... |
| - self sealing adaptor | 1-CT-019-2-.....-..... |

In case that both coupling halves are not connected they should be protected against external dirt and/or damages if required.

For that purpose dust cap and dust plug are available.

Possible combinations :

- | | |
|-----------------------------------|---|
| self sealing coupling
dust cap | 1-CT-005-0 with
1-SK-028-9-17325-AAAA-T015 |
| self sealing adaptor
dust cap | 1-CT-005-2 with
1-SL-014-9-17325-AAAA-T022 |
| self sealing coupling
dust cap | 1-CT-007-0 with
1-SK-033-9-22328-AAAA-T017 |
| self sealing adaptor
dust cap | 1-CT-007-2 with
1-SL-018-9-17325-AAAA-T028 |
| self sealing coupling
dust cap | 1-CT-009-0 with
1-SK-035-9-24430-AAAA-T017 |
| self sealing adaptor
dust cap | 1-CT-009-2 with
1-SL-020-9-24430-AAAA-T030 |
| self sealing coupling
dust cap | 1-CT-012-0 with
1-SK-040-9-35442-AAAA-T017 |
| self sealing adaptor
dust cap | 1-CT-012-2 with
1-SL-022-9-35442-AAAA-T030 |
| self sealing coupling
dust cap | 1-CT-019-0 with
1-SK-058-9-47455-AAAA-T020 |
| self sealing adaptor
dust cap | 1-CT-019-2 with
1-SL-035-9-44450-AAAA-T046 |

We recommend:

The self sealing adaptors should be rigidly mounted and the self sealing couplings should be used as free parts which protects the sealing faces.

Product description of coupling

5.1 Intended Use

- The Clean Break couplings of the CT series are our latest generation push to connect couplings for low pressure applications (up to 64 bar).
- The clean break coupling serves only to connect two lines.
- Connection under residual pressures.

Type	CT-005	CT-007	CT-009	CT-012	CT-019
can be connected under residual pressure	25 bar 362 psi	15 bar 217 psi	15 bar 217 psi	8 bar 116 psi	4 bar 58 psi

- The connection and disconnection process is carried out manually.
- The coupling has an automatic lock, i.e.

one-hand operation

- The connection and disconnection is performed without squirting medium.
- This series is suitable for all applications which demand minimal leakage, fool-proof handling and a high flow rate.
- For all other possible media Walther Präzision should be consulted.

5.2 Technical data

- Working pressures of coupling depend on materials of individual parts.
- When determining the working with standardized threaded connections, the highest permissible working pressure of the connection must be taken into account.
- When selecting a suitable connection the following static pressure is possible:

	Max. working pressure connected bar / psi	Max. working pressure disconnected bar / psi	Amount of Leakage (ml)	Cv-value
CT-005	64 / 928	30 / 435	0,1	0,8
CT-007	64 / 928	30 / 435	0,1	1,85
CT-009	64 / 928	30 / 435	0,1	2,75
CT-012	64 / 928	30 / 435	0,15	4,5
CT-019	40 / 580	30 / 435	0,3	9,8

- The coupling is not determined for any types of use and technical values other than those listed here.
- Safe operation is not guaranteed if the coupling is used contrary to its intended use and technical values
- The operator of the coupling is responsible for all personal injuries or material damage that occur from non-intended use and disregard of the technical values; the manufacturer assumes no responsibility in these cases.

Product description of coupling

5.3 Optional Features

GG = with ring grips (aluminium cast)
only **CT-019** (z.B.: 1-CT-019-0-.....-...-GG)



EX = ATEX – version

5.4 Extended product description for application acc. to ATEX-guide line 94/9/EG (special design EX):

5.4.1 General

Only non-sparkling materials may be used.
Non-sparkling materials are 1.4404, 1.4571 or equivalent materials.
Furthermore brass with different surfaces (f. ex. chrome-plated, nickel-plated).

Further on it must be assured that the seal is resistant against and suitable for the flowing through media. Also the temperature resistance of the seals must be guaranteed. This must also be considered for the marking acc. to chapter 5.5.2.

5.4.2 Extended marking

The coupling fittings are marked with



As the surface temperature of the self-sealing couplings are determined by the temperature of the fluids, the temperature category or the highest surface temperature must be specified by the operator while the safe temperature distances acc. to EN 13463-1 must be observed and the maximum temperature resistance of the coupling materials and seals are taken into consideration.

The marking of the temperature class must be effected readily visible by the operator.

The determination of the temperature class must be made acc. to the following table:

Max. temperature of fluids	Temperature class
75	T6
90	T5
130	T4
195	T3
295	T2
445	T1

The couplings are not admitted for the temperature classes T1 and T2 and may not be marked for that by the operator.

6 Installation manual

6.1 General

The coupling is to be integrated into the line network while taking into account the general accident prevention guidelines so that:

- perfect operation is guaranteed in accordance with the operating manual.
- the coupling is primarily used by the network and the adaptor is primarily used by the consumer side.
- external damage to the unit and all mobile parts is excluded.

Before installing the coupling in a pipeline network, make sure that the pipeline network has been sufficiently rinsed/blown through and/or cleaned.



After completing the assembly work, a function test must be carried out according to the operating manual, both in depressurized state and under working pressure.

6.2 Extended installation instruction for application acc. to ATEX-guideline 94/9/EG

6.2.1 Details for safe operation

For the use of self sealing couplings as a hose connection it must be guaranteed that in case of pressure strikes the tumbling of the self sealing coupling can be avoided by fixing at suitable constructions. In principle it must be observed that the self sealing coupling cannot strike on hard objects which could produce strike sparks when touching the housing.

6.2.2 Details for safe installation

The self sealing couplings may only be connected to pipe- and hose systems which are suitable for electrostatic discharge and which are connected to the ground potential.

6.2.3 Details for a safe application area

The self sealing couplings may be used according to the class of devices² in areas susceptible to explosions where potentially explosive mixtures of gas, steam, mist and air are available.

7 Operating manual

The self sealing coupling elements may only be used for the operating conditions specified under item 5 (product description) in order to avoid critical injury to personnel and damage to the self sealing coupling elements during operation.

7.1 Coupling process

Before each coupling process a visible check of the coupling and the adaptor has to be made. Damaged parts must be changed in case of observable, visible damages or deformations.

The self-sealing coupling is equipped with an automatic lock, i. e. one-hand operation. For coupling the self-sealing coupling behind the locking sleeve or the self-sealing adaptor in the end plug area is taken up with one hand and pushed axially centred on the counter piece until the end stop.

During the coupling the locking sleeve snaps in forward without the aid of the operator.

Now the self-sealing coupling and the self-sealing adaptor are locked mechanically. Available valves are opened during the coupling process and thus the passage is released.



CAUTION

Please take care that locking sleeve is in final position, i.e. that it is flush in front with the coupling housing as otherwise no perfect lock is guaranteed.

7.2 Uncoupling process

For decoupling the self sealing coupling behind the locking sleeve is taken up with one hand and the locking sleeve is pulled back with the other hand and thus the connection is separated.

After separating the connection the locking sleeve slides back to its initial position for the next coupling procedure. This position is the same in the connected and disconnected condition.

During the decoupling the available valves close automatically so that no further discharge of media is possible.

Caution!

In case of an available pressure in the line connected by the coupling system a strong separation impulse - depending on the pressure - can be effective onto the coupling system during disconnection. For that reason the movable part of the coupling (free half) is to be firmly held in the hand to avoid injuries.

8 Maintenance and function test

Preventative maintenance measures

WALTHER self sealing couplings are to be handled in such a way that external damage to the elements and to all movable parts is excluded.

We recommend a slight greasing of the movable plug-in areas to minimize operating forces and to extend the service life of the self sealing couplings.

To always guarantee the function of the coupling and hence the safety of the operator a maintenance and a functional testing must be carried out within appropriate periods of time depending on the operating conditions.

8.1 Maintenance

- An external visual inspection for damage and contamination is to be carried out for the self sealing coupling and the self sealing adaptor.
- Contamination in the externally accessible function areas (sealing area, operating elements) is to be removed simply by wiping.

If there are damaged, torn or corroded parts, the clean break coupling must be dismantled and sent for repair to the manufacturer.

In the case of torn, brittle or old seals and with severe contamination, the customer must decide whether to send the clean break coupling to the manufacturer for repair work or whether he repairs himself.

8.2 Function test

As described in the operating manual, the clean break coupling is connected several times, pressurized and disconnected.

When doing this, pay attention to the following:

- Perfect, smooth-running functioning during connection and disconnection.
- Leak tightness of the clean break coupling when connected and disconnected .

If there are damaged, torn or corroded parts, the coupling must be dismantled and sent for repair to the manufacturer.

In the case of torn, brittle or old seals and with severe contamination, the customer must decide whether to send the clean break coupling to the manufacturer for repair work, or whether he repairs himself.

9 Lubrication !

We recommend lightly greasing the plug-in areas to minimize operating forces and to extend the service life of the coupling.

Lubrication has to be carried out with greases which do not tend to become resin.

Do **not** lubricate with resinous greases.

Attention !

The choice of grease with regard to compatibility must agree with the seal quality and the medium (e.g.: oxygen).

10 Storage

The couplings must be stored in such a way that no damage can occur to the couplings.

The storage conditions of the couplings depend on the guidelines applicable to the gaskets, since improper storage can lead to deterioration of the gaskets.

The following points must be observed:

- The couplings must be stored dry.
- For the preservation of the gaskets, the gaskets and couplings should not be stored where they are exposed to the effects of daylight.

For protection against oxygen, the gaskets and couplings should be stored in the original packaging.

11 Shut-down

At the end of the service life the coupling or its components have to be disposed non-polluting and according to the legal regulations.

For that the local public or private disposal societies should be taken.

12 Order numbers code

1. 2. 3. 4. 5. 6. 7. 8. 9.

X – X X - X X X – X – X X X X X – X X - X – X X X - X X

X – X X - X X X – X – X X X X X – X X X X – X X X - X X

1. Subject group
2. Series
The information regarding the series comprises either two letters or two numbers.
3. Nominal size / nominal borewidth
It is rounded up or down to one. The information can be numerical as well as alphanumerical.
4. Product type or design type
5. Connection design
6. Material design:
xx-x and xxxx possible
7. Material design (seal design):
xx-x and xxxx possible
8. Y or Z design
9. Additional equipment

13 Index

A

Accident prevention guidelines	10
According to intended purpose.....	6
Acquired knowledge.....	4
Alterations	4
Assembling.....	10
Assembly	6
Assembly work.....	10

C

clean break subassembly element.....	12
Cleaned.....	10
Commissioning.....	4, 6
connected.....	7
connection	7
Consumer side	10
Corroded.....	12
coupling.....	2, 6, 12, 13
Coupling	6, 8, 11, 12, 15
Couplings	6
Customer care.....	2

D

Damage.....	4, 6
Damage compensation	4
Damaged.....	12
Daylight.....	14
Depressurized	10
Depressurized state.....	10
Dismantling	6, 10
Disposal societies	15
Disregard	8
dry.....	14
dust cap.....	7
dust plug.....	7

E

Equipment	4
Experience	4

F

Faults	4
Function.....	6
Function test	6, 10, 12
Functionality.....	2

G

General	4
---------------	---

H

Hazard notes.....	6
Hazardous emission	6

I

Implementation	6
Improvement	4
Inspection	2
Installation manual.....	10

L

Legible condition	6
Liability	4
Lubrication	13

M

Maintenance	2, 4, 6, 12
Maintenance and function test	12
Manual	4
Medium	6
Mobile parts	10

N

Network side	10
--------------------	----

O

one-hand operation.....	11
Operating manual.....	1, 10
Operation.....	2
Operational safety regulations.....	6
Operator	6, 12
Operators.....	2
original	4
Oxygen	13

P

Packaging	14
Perfect operation	10
Perfect, functioning condition.....	6
Performance capability.....	2
Pipeline network	10
Pressurized	6
Product description	7
Property	4

R

Regulations.....	4
Reliability.....	2
Repair work.....	12

responsible..... 8

S

Safety..... 2
 Safety devices..... 6
 Scope of delivery..... 4
 Screw connections..... 6
 Seals 12
 self sealing adaptor..... 7
 Self sealing adaptor 10
 self sealing coupling..... 7
 Self sealing coupling 10
 Service..... 2
 Severe contamination 12
 Shut-down 15
 Smooth-running function 12
 Special designs 4
 Specialists..... 2
 Status of development 4
 Storage..... 14
 Storage conditions 14
 Systems..... 2, 6

T

Table of Contents 3
 Technical data 8
 Technical equipment..... 2
 Technical values..... 8
 Temperaturklasse 9
 Tools 2, 6
 Torn..... 12
 Translation errors 4
 Types of use 8

U

Use 2, 10

V

Version 4

W

Work safety regulations 6
 Working method 6
 working pressure 8
 Working pressure 10
 Wrong product selection 6